

Replacing the System Battery

This Tech Note applies to the ALR 7200, ALR 7300, ALR 8200, ALR 8300, and ALR 9200 systems.

The system battery can be found on the system board. This battery provides power to maintain the complimentary metal-oxide semi-conductor (CMOS) memory where the system configuration is stored.

If the system suffers from configuration errors or lost CMOS memory, replace the battery. The procedure for replacing the battery is described in the Maintaining and Troubleshooting manual that came with the system.

A MAN US 9200 CMOS BTY INST UPD R0 8504176

