


Processor update information

Although your documentation describes the Intel® Pentium® II Xeon™ processor, your server can also support Pentium III Xeon processors.

If you replace the Pentium III Xeon processor or add an additional one, follow the directions in your server maintaining and troubleshooting guide for installing a Pentium II Xeon processor.

Disregard the steps for setting processor speed with system board jumpers if you are installing a Pentium III Xeon processor. The processor automatically sets your processor speed.

A MAN US PII/PIII XEON UPD R0 4/99



8504671