




Setup Poster

Gateway Convertible Notebook PC

Connecting Wirelessly

Your Gateway Convertible Notebook PC has built-in wireless networking. To take full advantage of your Convertible Notebook PC's wireless capabilities, you can set up a wireless network in your home or business. After your network is set up, you can wirelessly browse the Internet, send e-mail, transfer files, and print. For more information on setting up a network, see the printed wireless networking guide.




Getting Additional Help

Printed manuals include the *Gateway Convertible Notebook PC User Guide* and the *Gateway Notebook Networking Guide*.


To learn more about using Windows, creating CDs and DVDs, editing movies, and using Internet Explorer, click **Start**, then click **Help and Support**, or click **Start, All Programs**, then click **Gateway Documentation** and see *Using Your Computer*.



You can get device drivers, FAQs, product specifications, and other useful information at support.gateway.com.




For Customer Care (technical support) telephone numbers, see the label on the bottom of your Convertible Notebook PC.



Working Securely

Your Gateway Convertible Notebook PC comes with the software you need to connect safely and securely. To ensure a high level of security, you should:

- Regularly update your antivirus software.
- Install all critical updates for Microsoft Windows (click **Start, All Programs**, then click **Windows Update** and follow the on-screen instructions).
- Use the security features provided in the Windows Security Center (click **Start, All Programs, Accessories, System Tools**, then click **Security Center**).



Managing Your Battery Life

To get the most out of your battery:

- Dim the display as low as you can comfortably see.
- Remove PC Cards when not using them.
- Modify the power management settings to reduce power use.
- Use Hibernate mode when not using your notebook.
- Use the Optical drive only when you need to.
- Travel with an extra battery and fully charge batteries before traveling.
- Use your AC power adapter whenever power is available.

For more information, see "Managing Power" in your user guide.



8 27103 07554 0
MAN VIPER POSTER R1 8/05

8510993